

## HEATING CONTROLS



- 1) This adds one additional hour of heating to your current heating cycle. i.e. when running your heating programme, if due to turn off at 8pm, will continue until 9pm.
- 2) Override button, if your heating is on programme and currently off, this will turn your heating on until the next heating cycle. If your heating is currently on, this will switch it off until the next heating cycle
- 3) This button does not function in your property
- 4) Use this button to select whether your Heating is Off, on a timed programme or constantly on.
- 5) Use this to select heating programme.

## RADIATOR CONTROLS



This Control sets the temperature of your radiator. Setting 5 is the highest temperature and 1 the lowest. If you feel a room is too warm when heating on (but you still need your heating on) lower the setting on this control. Below are the approximate temperatures of each setting.

- 1) 10°C
- 2) 18°C
- 3) 20°C
- 4) 23°C
- 5) 26°C